

RoughCutter

Maße	RCH 1365 4.00-8 Ackerstolle	RCH 1680 5.00-10 Ackerstolle	RCH 1680 Zwillingsbereifung 4.00-8 Ackerstolle	RCH 1680 Zwillingsbereifung 5.00-10 Ackerstolle	RCH 18100 18 x 9.50- 8 Ackerstolle	RCH 18100 Zwillingsbereifung 18 x 9.50- 8 Ackerstolle
A: Arbeitsbreite [cm]	65	80	80	80	100	100
B: Breite [cm]	94	109	109	109	129	129
C: Länge [cm]	240	240	240	240	240	240
D: Höhe [cm]	125	125	125	125	125	125
Gewichte						
Grundgerät [kg]	265	281	281	90	305	305

